


## Details


Dimensions		
DN/WxH	G	F
600-2000	150	250

Section A-A



After fastening of the hollow spaces of the frame sealing by cement mortar<sup>1)</sup>


Compound anchor bolt



## WAGU® Slide Penstocks with Skids GK1

For anchor bolting and sealing by cement mortar, with round sill for grouting.

### Structure Recesses



### Mounting Instructions

- ➔ Place frame with door at the desired position and align.
- ➔ In the frame or at the fastening angles there are double bolt holes, diagonally displaced.
- ➔ Thus, you can always use alternative holes if on drilling e.g. you come across a concrete reinforced iron.
- ➔ The bolt holes in the frame are 2 mm larger than the drill and should be used as guide for drilling.
- ➔ For fastening compound anchor bolts have to be used.

#### Sealing the frame towards the wall

- ➔ Prior to fastening the Penstock on the wall, a sealing tape is applied on the back of the frame for sealing by cement mortar.
- ➔ On request, we'll supply fastening parts and sealing tape, too.
- ➔ Within the area of the facings of the wall sealing, the concrete wall has to be even.
- ➔ When screwing on the fastening nuts take care that the penstock frame sits close to the wall in a uniform manner. Distortion of the frame affects performance and tightness of the Penstock.
- ➔ Grout the sill with grouting mortar.
- ➔ The hollow space of the frame between wall and frame has to be sealed with grouting mortar<sup>1)</sup>.

When sealing by grouting mortar, no mortar must touch the seal or the door. Possible impurities have to be removed immediately.

<sup>1)</sup> We recommend to use a grouting mortar based on cement, e.g. VGM Superfluid of TRICOSAL company, or similar.